ĐẠI HỌC QUỐC GIA TP. HÒ CHÍ MINH

TRƯỜNG ĐẠI HỌC BÁCH KHOA KHOA ĐIỆN – ĐIỆN TỬ

> BK TP.HCM

TIỂU LUẬN MÔN: THỊ GIÁC MÁY

KIỂM TRA DÁN NHÃN VÀ MỰC NƯỚC CỦA SẢN PHẨM BẰNG THỊ GIÁC MÁY

GVHD: TS. Nguyễn Đức Thành

STT	HQ VÀ TÊN	MSSV
1	Nguyễn Hoàng Ân	1610137
2	Hồ Hưng Duy	1651017
3	Lê Giang Nam	1612102
4	Đinh Phước Lộc	1710178

TP. HÒ CHÍ MINH, THÁNG 12 NĂM 2019

MŲC LŲC

1. GI	ÓІ ТНІЁ́U	1
1.1	Tổng quan đề tài	1
1.2	Nhiệm vụ đề tài	2
1.3	Phân chia công việc trong nhóm	2
2. LÝ	Ý THUYẾT VỀ XỬ LÝ ẢNH	3
2.1	Lân cận 8 của 1 pixel:	3
2.2	Phân ngưỡng Otsu:	4
2.3	Bộ lọc Gaussian:	5
2.4	Contour	6
3. QU	JÁ TRÌNH THỰC HIỆN	7
3.1	Sơ đồ khối	7
3.2	Các mẫu ảnh và các trường hợp test	14
3.3	Thực hiện lập trình	16
3.4	Kết quả đạt được	39

DANH SÁCH HÌNH MINH HỌA

Hình 1. Hình minh họa dây chuyền chiết rót và đóng chai tự động	1
Hình 2. Hình ảnh minh họa quy trình kiểm tra mực nước bằng mắt	2
Hình 3. Hình minh họa dây chuyền tự động hóa công đoạn kiểm tra mực nước	2
Hình 4. Ma trận lọc Gauss	6
Hình 5. Kết quả trước và sau khi sử dụng phép toán Opening	7
Hình 6. Mẫu chai đat yêu cầu về nhãn và mưc nước	14

1. GIỚI THIỆU

1.1 Tổng quan đề tài

Dây chuyền đóng chai, đóng gói sản phẩm tự động là một trong những là dây chuyền tiên tiến, hiện đại giúp các doanh nghiệp, xưởng sản xuất tiết kiệm được thời gian, chi phí và tăng năng suất công việc. Toàn bộ quá trình chiết rót đều được thực hiện theo một quy trình khép kín nghiêm ngặt nhằm đảm bảo chất lượng sản phẩm.



Hình 1. Hình minh họa dây chuyền chiết rót và đóng chai tự động

Một quy trình đóng chai, đóng gói tự động, sản phẩm, là tổng hợp của các tác vụ nối tiếp hoặc song song, theo một vòng lặp nhất định. Các tác vụ đó thể là: vệ sinh vật chứa, chiết rót, đóng chai, dán nhãn, kiểm tra chất lượng... Mỗi khâu có một tầm quan trọng khác nhau, nhưng đều ảnh hưởng trực tiếp đến kết quả chất lượng của sản phẩm.

Một trong những tác vụ được đánh giá là mang ý nghĩa quyết định đó là khâu kiểm tra diện ngoài của sản phẩm. Lấy ví dụ với dây chuyền sản xuất nước đóng chai. Các yêu cầu các loại sản phẩm liên quan đến chất lỏng, luôn chú trọng đến mực chất lỏng bên trong chai, cũng như các bao bìa, dán nhãn bên ngoài.

Với mực chất lỏng trong chai, theo phương thức truyền thống, các công nhân trong nhà máy sẽ là người chịu trách nhiệm với khâu này. Phương thức được thực hiện khá đơn giản, là cho băng chuyền chạy qua một màn đèn neon, các công nhân có nhiệm vụ dùng mắt thường, để kiểm tra nước trong chai đã đạt tiêu chuẩn chưa. Việc kiểm tra bao bì sản phẩm cũng vậy, người công nhận sẽ nhận dạng được các sản phẩm đã đạt hoặc bị lỗi việc dán nhãn.



Hình 2. Hình ảnh minh họa quy trình kiểm tra mực nước bằng mắt

Với mục đích tối ưu nguồn nhân công, tự động hóa quy trình sản xuất, các nhà phát triển đã áp dụng những phương thức mới, áp dụng kỹ thuật mới vào các khâu sản xuất, đặc biệt là khâu phát hiện lỗi sai về mực chất lỏng trong chai và lỗi dán nhãn bao bì. Vì đặc trưng của các khâu trên cần sự quan sát, nhận dạng, và đưa ra kết luận, Xử Lý Ảnh trong công nghiệp là lĩnh vực được nghiên cứu và phát triển hàng đầu. Nhóm nghiên cứu chúng em cũng dựa vào những đặc điểm, mục tiêu của công việc, để thực hiện nghiên cứu đề tài này.



Hình 3. Hình minh họa dây chuyền tự động hóa công đoạn kiểm tra mực nước

1.2 Nhiệm vụ đề tài

- Nội dung 1: Thực hiện nghiên cứu và nắm vững một số giải thuật xử lý ảnh
- Nội dung 2: Thực hiện lấy mẫu ảnh để thực hiện chạy thử các mô hình
- Nội dung 3: Nhận dạng và phát hiện lỗi mực nước và lỗi dán nhãn

1.3 Phân chia công việc trong nhóm


Nhiệm vụ	Thành viên phụ trách	Ghi chú

Nghiên cứu sâu các giải thuật xử lý ảnh	Hưng Duy + Phước Lộc
Nghiên cứu các phương pháp Machine Learning	Giang Nam + Hoàng Ân + Phước Lộc
Thực hiện lấy mẫu ảnh và video	Cả nhóm
Lập trình và thử nghiệm trên mẫu ảnh và video	Hung Duy + Giang Nam + Phước Lộc
Tổng hợp báo cáo	Hoàng Ân

2. LÝ THUYẾT VỀ XỬ LÝ ẢNH

- Conneted component (8)
- Phân ngưỡng otsu & Bộ lọc Gause
- Contour

2.1 Lân cận 8 của 1 pixel



• Xét 1 pixel p tại (x,y):

- Lân cận-4 của p, $N_4(p)$: các điểm có tọa độ tại (x+1,y), (x-1,y), (x,y+1), (x,y-1).
- Lân cận chéo-4 của p, $N_D(p)$: (x+1,y+1), (x+1,y-1), (x-1,y+1), (x-1,y-1).
- Lân cận-8 của p, $N_8(p)$: $N_4(p)$ và $N_D(p)$.

• Kết nối giữa 2 pixel:

2 pixel p và q được gọi là kết nối nếu chúng là lân cận tương ứng và mức xám của chúng thỏa tiêu chuẩn tương đồng V.

- Kết nối-4: $q \in N_4(p)$.
- Kết nổi-8: $q \in N_8(p)$.
- Kết nối hỗn hợp-m: thỏa 1 trong 2 điều kiện sau
 - \circ $q \in N_4(p)$.
 - $\circ \quad q \in N_D(p) \text{ và } N_4(p) \cap N_4(q) = \emptyset.$

• Do khoảng cách:

Cho các pixels p, q và z có tọa độ (x,y), (s,t), (u,v) tương ứng, hàm khoảng cách D có các đặc tính sau:

a.
$$D(p, q) \ge 0$$
 $[D(p, q) = 0, \text{ if } p = q]$

b.
$$D(p, q) = D(q, p)$$

c.
$$D(p, z) \le D(p, q) + D(q, z)$$

Euclidean distance:

$$D_{\rho}(p, q) = [(x - s)^2 + (y - t)^2]^{1/2}$$

City block distance:

$$D_4(p, q) = |x - s| + |y - t|$$

Chess board distance:

$$D_8(p, q) = \max(|x - s|, |y - t|)$$

2.2 Phân ngưỡng Otsu

• Khái niệm phân ngưỡng:

Phân ngưỡng ảnh là tách hình ảnh của một một vùng ảnh ra khỏi ảnh nền.

• Lược đồ xám (Histogram):

Là một đồ thị dạng thanh biểu diễn tần suất xuất hiện các mức xám của ảnh. Trong đó trục hoành biểu diễn giá trị mức xám của ảnh có giá trị từ 0 đến 255, trục tung biểu diễn tần suất xuất hiện mức xám của ảnh.

Công thức tổng quát:

$$p(r_k) = \frac{n_k}{MN} \tag{1.1}$$

Trong đó:

 $p(r_k)$ là tần suất xuất hiện mức xám

n_k là giá trị điểm ảnh tại vị trí k

M,N: kích cỡ ma trân ảnh.

• Thuật toán Otsu:

- Lặp với tất cả giá trị ngưỡng.
- Úng với mỗi giá trị ngưỡng, đo phương sai kết hợp cùng lớp (σ_W) dựa trên phương sai của vùng nền (σ_b) và vùng cảnh (σ_f) với trọng số xác suất (W_b, W_f) tương ứng.
- Giá trị ngưỡng tương ứng với phương sai cùng lớp nhỏ nhất.

Within Class Variance
$$\sigma_W^2 = W_b \sigma_b^2 + W_f \sigma_f^2$$
:

- Có thể cải tiến nhanh hơn dùng đo phương sai kết hợp giữa lớp (σ_B) lớn nhất.

Between Class Variance
$$\sigma_B^2 = \sigma^2 - \sigma_W^2$$

 $= W_b(\mu_b - \mu)^2 + W_f(\mu_f - \mu)^2$
 $= W_b W_f (\mu_b - \mu_f)^2$

- Trình tư thực hiện:
 - 1. Sử dụng lược đồ Histogram biểu diễn tần suất xuất hiện mức xám
 - 2. Chọn một ngưỡng $T_k = k$, (0 < k < L-1) để phân ảnh đầu vào thành 2 lớp C_1 (tập hợp các điểm ảnh có giá trị $\leq k$) và C_2 (tập hợp các điểm ảnh có giá

trị lớn hơn k). Tỉ lệ lớp C_1 với số lượng điểm ảnh k với tổng số lượng điểm ảnh được ký hiệu $P_1(k)$, tương tự C_2 ký hiệu là $P_2(k)$.

$$P_1(k) = \sum_{i=0}^{k} p_i \tag{1.2}$$

$$P_2(k) = \sum_{i=k+1}^{L-1} p_i = 1 - P_1(k)$$
(1.3)

Sau đó tính giá trị trung bình m₁ của lớp C₁

$$m_1(k) = \sum_{i=0}^{k} iP\left(\frac{i}{C_1}\right) = \frac{1}{P_1(k)} \sum_{i=0}^{k} iP_i$$
 (1.4)

Tương tự, ta tính m₂ của C₂

$$m_2(k) = \sum_{i=k+1}^{L-1} iP\left(\frac{i}{C_2}\right) = \frac{1}{P_2(k)} \sum_{i=k+1}^{L-1} iP_i$$
 (1.5)

3. Theo Otsu, ta sẽ tính ngưỡng k* mà giá trị tại đó sự chênh lệch giữa hai đoạn (màu nền và màu ký tự) đạt giá trị cực đại, ký hiệu $\sigma_B^{\ 2}(k^*)$, được tính:

$$\sigma_B^2(k^*) = \underset{0 \le k \le L-1}{\text{Max}} \sigma_B^2(k)$$
(1.6)

Trong đó $\sigma_{\mathbf{B}}$ là phương sai hai lớp C_1 và C_2 . Ta có:

$$\sigma_{B}^{2} = P_{1}(m_{1} - m_{G})^{2} + P_{2}(m_{2} - m_{G})^{2}$$

$$= P_{1}P_{2}(m_{1} - m_{2})^{2}$$

$$= \frac{(m_{G}P - m)^{2}}{P_{1}(1 - P_{1})}$$

Từ công thức trên ta suy ra:

$$\sigma_{B}^{2}(k) = \frac{\left[m_{G}P_{1}(k) - m(k)\right]^{2}}{P_{1}(k)\left[1 - P_{1}(k)\right]}$$
(1.7)

Trong đó:

- m_G là giá trị trung bình của ảnh.

.
$$m_G = \sum_{i=0}^{L-1} i p_i \text{ hoặc } m_G = P_1 m_1 + P_2 m_2$$
 .


- m_k là giá trị trung bình đến ngưỡng k. Với $m_k = \sum_{i=0}^k i p_i$.

Nếu có nhiều giá trị σ^2_B lớn nhất bằng nhau, ta sẽ chọn k có giá trị lớn nhất làm ngưỡng k*, sau đó ta thực hiện nhị phân biển số theo theo ngưỡng.

2.3 Bộ lọc Gaussian:

Bộ lọc Gauss được cho là bộ lọc hữu ích nhất, được thực hiện bằng cách nhân chập ảnh đầu vào với một ma trận lọc Gauss sau đó cộng chúng lại để tạo thành ảnh đầu ra.

- Ý tưởng chung là giá trị mỗi điểm ảnh sẽ phụ thuộc nhiều vào các điểm ảnh ở gần hơn là các điểm ảnh ở xa. Trọng số của sự phụ thuộc được lấy theo hàm Gauss (cũng được sử dụng trong quy luật phân phối chuẩn).
- Dưới đây là biểu diễn ma trận lọc Gauss:



Hình 4. Ma trận lọc Gauss

Giả sử ảnh là một chiều. Điểm ảnh ở trung tâm sẽ có trọng số lớn nhất. Các điểm ảnh ở càng xa trung tâm sẽ có trọng số giảm dần khi khoảng cách từ chúng tới điểm trung tâm tăng lên. Như vậy điểm càng gần trung tâm sẽ càng đóng góp nhiều hơn vào giá trị điểm trung tâm.

Chú ý: Trên thực tế, việc lọc ảnh dựa trên hàm Gauss 2 chiều (ngang và dọc). Phân phối chuẩn 2 chiều có thể biểu diễn dưới dạng:

$$G(x,y)=rac{1}{2\pi\sigma^2}e^{-rac{x^2+y^2}{2\sigma^2}}$$

Hoăc:

$$G_0(x,y) = Ae^{rac{-(x-\mu_x)^2}{2\sigma^2_x} + rac{-(y-\mu_y)^2}{2\sigma^2_y}}$$

Trong đó μ là trung bình (đỉnh), σ^2 là phương sai của các biến số x và y.

Tham số μ quyết định tác dụng của bộ lọc Gauss lên ảnh. Độ lớn của ma trận lọc (kernel) cần được lựa chọn cho đủ rộng.

2.4 Contour

Contour là "tập các điểm-liên-tục tạo thành một đường cong (curve) (boundary), và không có khoảng hở trong đường cong đó, đặc điểm chung trong một contour là các các điểm có cùng /gần xấu xỉ một giá trị màu, hoặc cùng mật độ. Contour là một công

- cụ hữu ích được dùng để phân tích hình dạng đối tượng, phát hiện đối tượng và nhận dạng đối tượng".
- Để tìm contour chính xác, chúng ta cần phải nhị phân hóa bức ảnh (không phải ảnh grayscale). Các kỹ thuật nhị phân hóa ảnh ở xử lý ảnh cơ bản có thể liệt kê đến là đặt ngưỡng, hoặc candy edge detection.
- Trong opency, việc tìm một contour là việc tìm một đối tượng có màu trắng trên nền đen.

2.5 Opening

- Opening là một trong những phép toán điển hình của các phép toán hình thái học. Phép Opening được thực hiện bằng phép co (Erosion) trước sau đó mới thực hiện phép giãn nở (Dilation).
- Công thức:

$A \bigcirc B = (A \ominus B) \oplus B$

- Úng dụng: Phép toán mở (Opening) được ứng dụng trong việc loại bỏ các phần lồi lõm và làm cho đường bao các đối tượng trong ảnh trở nên mượt mà hơn.
- Ví dụ: sử dụng phép Opening trong python


opening = cv.morphologyEx(img, cv.MORPH_OPEN, kernel)

Và kết quả như hình bên dưới:




Hình 5. Kết quả trước và sau khi sử dụng phép toán Opening

3. QUÁ TRÌNH THỰC HIỆN 3.1 Sơ đồ khối




b. Sơ đồ tìm tỉ lệ: $\frac{\textit{Mức nước}}{\textit{Chiều cao chai trong ảnh đúng}} \, (1)$




c. Sơ đồ tìm các tỉ lệ (2) và (4):


Chiều cao nhãn
Chiều cao nước;
Chiều cao chai




d. Tìm chai nước và các thông số chai nước (3)



e. Sơ đồ khối tỉ lệ $\frac{\textit{Mức nước}}{\textit{Chiều cao trong ảnh Test}}$ (5)



f. Sơ đồ kiểm tra nhãn có hay không (6)



3.2 Các mẫu ảnh và các trường hợp test
Quy trình thực hiện của nhóm áp dụng theo sơ đồ được thể hiện ở bên trên. Nhóm chọn chai nước giải khác Coca-Cola để thực hiện đề tài. Sau đây là mẫu đúng của sản phẩm:



Hình 6. Mẫu chai đạt yêu cầu về nhãn và mực nước

Các trường hợp lỗi, không đạt yêu cầu:

Nhãn bị dán sai vị trí. Đặc điểm của bức hình là:

- Có thể thấy nhãn đã bị dán sai vị trí so theo chiều dọc.
- Không thể nhận biết được là mực nước có đúng hay không.



Nhãn bị dán lệch vị trí và mực nước thấp hơn mực nước chuẩn.



Trường hợp không có nhãn và mực nước thấp hơn mực nước chuẩn.



Trường hợp dán nhãn đúng, nhưng mực nước thấp hơn mực nước chuẩn.



Trường hợp dán nhãn đúng, nhưng mực nước thấp hơn mực nước chuẩn.



3.3 Thực hiện lập trình

Nhóm chọn ngôn ngữ lập trình là Python, với thư viện OpenCV.

#
This software is using for checking the liquid volume and the label position of bottle. This background
of this project is white and the object is Coca Cola bottle.
#
import cv2
from PIL import Image
import matplotlib.pyplot as plt

```
import numpy as np
import os, sys
import configparser
import argparse
from pylab import *
import imutils
from imutils import perspective
from scipy.spatial import distance as dist
from imutils import contours
from datetime import datetime
# This is configuration for ROI
config = configparser.ConfigParser()
config.read("system.ini")
IMAGES_MASK = config.get("path", "images_mask")
SOURCE_IMAGES_PATH = config.get("path", "source_dir")
RESULT_IMAGES_PATH = config.get("path", "result_dir")
CUT_BORDER = config.getfloat("geometry", "cut_border")
PRE_ROI_WIDTH = config.getfloat("geometry", "pre_roi_width")
ROI_WIDTH = config.getfloat("geometry", "roi_width")
# ------
# Threshold to detect label (relative)
LABEL_H_MIN = 0
LABEL_H_MAX = 250
LABEL_S_MIN = 142
LABEL_S_MAX = 255
LABEL V MIN = 106
LABEL_V_MAX = 255
#-----
# threshold for liquid level
LIQUID_LEVEL_H_MIN = 0
LIQUID_LEVEL_H_MAX = 255
LIQUID_LEVEL_S_MIN = 0
LIQUID\_LEVEL\_S\_MAX = 111
LIQUID\_LEVEL\_V\_MIN = 0
LIQUID_LEVEL_V_MAX = 111
```

```
#------
BANG HEIGHT = 0.2
#-----
def input image(path):
     image = cv2.imread(path, 1)
     image = cv2.resize(image, None, fx=0.3, fy=0.3, interpolation=cv2.INTER_CUBIC)
     image_e = cv2.cvtColor(image, cv2.COLOR_BGR2RGB)
     return image
#-----
def midpoint(ptA, ptB):
     return ((ptA[0] + ptB[0]) * 0.5, (ptA[1] + ptB[1]) * 0.5)
def his_enhance(image):
     image = cv2.cvtColor(image, cv2.COLOR_BGR2GRAY)
     image = cv2.equalizeHist(image)
     image = cv2.cvtColor(image, cv2.COLOR_GRAY2BGR)
     return image
#-----
def get_roi(image, left_border, right_border):
 image_h, image_w, _ = image.shape
 left_part = image[:, 0:left_border]
 right_part = image[:, right_border:image_w]
 return np.column_stack((left_part, right_part))
def find_background(image, roi):
 image_h, image_w, _ = image.shape
 hsv_img = cv2.cvtColor(image, cv2.COLOR_BGR2HSV)
 hsv_roi = cv2.cvtColor(roi, cv2.COLOR_BGR2HSV)
 roi_hist = cv2.calcHist([hsv_roi], [0, 1], None, [180, 256], [0, 180, 0, 256])
 mask = cv2.calcBackProject([hsv_img], [0, 1], roi_hist, [0, 180, 0, 256], 1)
 ksize = int(0.005 * image_h)
 kernel = cv2.getStructuringElement(cv2.MORPH_ELLIPSE, (5, 5))
 mask = cv2.filter2D(mask, -1, kernel)
  _, mask = cv2.threshold(mask, 30, 255, cv2.THRESH_BINARY | cv2.THRESH_OTSU)
 return mask
```

```
def get_pre_borders(mask):
       components
                      =
                          cv2.connectedComponentsWithStats(mask,
                                                                         connectivity=8,
ltype=cv2.CV_32S)
       _, labelmap, stats, centers = components
       st = stats[:, 3]
       largest = np.argmax(st)
       st[largest] = 0
       second = np.argmax(st)
       left = stats[second, 0]
       width = stats[second, 2]
       right = left + width
       roi_width = int(width * ROI_WIDTH)
       return left, right, roi_width
def ConnectedComponents(bin1):
       components
                            cv2.connectedComponentsWithStats(bin1,
                                                                         connectivity=8,
ltype=cv2.CV_32S)
       _, labelmap, stats, centers = components
       st = stats[:, 4]
       st_y = stats[:, 1]
       S_{largests} = [np.argmax(st)]
       S1000 = np.where(st > 1000)
       st_arg = S1000[0]
       number_label = len(st_arg)
       mask_bin = np.zeros(bin1.shape, dtype=np.uint8)
       if (len(st_arg) > 2):
              # Bang /lid area
              S_smallest_arg = np.argmin(st)
              left_bang = stats[S_smallest_arg,0]
              top_bang = stats[S_smallest_arg,1]
              right_bang = left_bang + stats[S_smallest_arg,2]
              bottom_bang = top_bang + stats[S_smallest_arg,3]
              # liquid level in axis y => max
              y_max_arg = np.argmax(st_y)
              left_liq = stats[y_max_arg,0]
```

```
top_liq = stats[y_max_arg,1]
              right_liq = left_liq + stats[y_max_arg,2]
              bottom_liq = top_liq + stats[y_max_arg,3]
              mask_bin[top_bang:bottom_bang,left_bang:right_bang] = 255
              mask_bin[top_liq:bottom_liq,left_liq:right_liq] = 255
       return number label, mask bin
def get_bottle_mask(bin):
       def clean(cln_bin, larg_num):
              components = cv2.connectedComponentsWithStats(cln bin, connectivity=8,
ltype=cv2.CV_32S)
              _, labelmap, stats, centers = components
              st = stats[:, 4]
              largests = [np.argmax(st)]
              st[largests[0]] = 0
              largests.append(np.argmax(st))
              cln_bin = np.zeros(cln_bin.shape, dtype=np.uint8)
              cln_bin[labelmap == largests[larg_num]] = 255
              return cln_bin, stats[largests[0]]
       bin, _ = clean(bin, 1)
       bin = cv2.bitwise\_not(bin)
       bin, stats = clean(bin, 0)
       left = stats[0]
       top = stats[1]
       right = left + stats[2]
       bottom = top + stats[3]
       mask = bin[top:bottom, left:right]
       mask = cv2.merge((mask, mask, mask))
       return mask, left, top, right, bottom
# The liquid level segmantation
def liqlevel_segmentation(image):
       image_h, image_w, _ = image.shape
       center_img = image[:, int(image_w * 0.03): int(image_w * 0.97)]
       blur = int(0.015 * image_w)
       center_h, center_w, _ = center_img.shape
```

```
img_hsv = cv2.cvtColor(center_img, cv2.COLOR_RGB2HSV)
                            cv2.inRange(img_hsv,
      filtered
                                                       (LIQUID_LEVEL_H_MIN,
LIQUID LEVEL S MIN,
                             LIQUID LEVEL V MIN), (LIQUID LEVEL H MAX,
LIQUID_LEVEL_S_MAX, LIQUID_LEVEL_V_MAX))
      binary = cv2.GaussianBlur(filtered, (5,5), 15)
             binary
                            cv2.threshold(binary,50,255,cv2.THRESH_BINARY
      ret,
cv2.THRESH_OTSU)
      binary = cv2.GaussianBlur(filtered, (15,15), 15)
                            cv2.threshold(binary,50,255,cv2.THRESH_BINARY
             binary
      ret,
cv2.THRESH OTSU)
      binary = cv2.GaussianBlur(filtered, (15,15), 15)
                            cv2.threshold(binary,50,255,cv2.THRESH_BINARY
             binary
      ret.
cv2.THRESH OTSU)
      kernel = cv2.getStructuringElement(cv2.MORPH_ELLIPSE, (5, 5))
      binary = cv2.morphologyEx(binary, cv2.MORPH_CLOSE, kernel)
      binary =cv2.bitwise_not (binary)
      return binary
# Label segmentation
def label_segmentation(image):
      image_h, image_w, _ = image.shape
      center img = image[:, int(image w * 0.03): int(image w * 0.97)]
      blur = int(0.015 * image_w)
      center_h, center_w, _ = center_img.shape
      img_hsv = cv2.cvtColor(center_img, cv2.COLOR RGB2HSV)
                     cv2.inRange(img hsv,
                                             (LABEL_H_MIN,
                                                                 LABEL_S_MIN,
LABEL_V_MIN),(LABEL_H_MAX, LABEL_S_MAX, LABEL_V_MAX))
      binary = cv2.GaussianBlur(filtered, (5,5), 15)
      ret.
             binary
                            cv2.threshold(binary,50,255,cv2.THRESH BINARY
cv2.THRESH_OTSU)
      binary = cv2.GaussianBlur(filtered, (15,15), 15)
                            cv2.threshold(binary,50,255,cv2.THRESH_BINARY
      ret.
             binary
cv2.THRESH_OTSU)
      binary = cv2.GaussianBlur(filtered, (15,15), 15)
                            cv2.threshold(binary,50,255,cv2.THRESH_BINARY
      ret,
             binary
cv2.THRESH_OTSU)
      binary =cv2.bitwise not (binary)
      kernel = cv2.getStructuringElement(cv2.MORPH_RECT, (15, 15))
```

```
binary = cv2.morphologyEx(binary, cv2.MORPH_OPEN, kernel)
      return binary
        _____
# Check the existence of label
def check label exist(image, S good label):
      binary = label segmentation(image)
      cv2.imshow('binary-check_label_exist',binary)
      contours,
                                   cv2.findContours(binary,
                                                               cv2.RETR TREE,
cv2.CHAIN_APPROX_SIMPLE)
      print('Length of contours-testbefore: check_lablels_exist()',len(contours))
      try:
            if (len(contours) >= 2):
                   c = max(contours, key = cv2.contourArea)
                   contours.remove(c)
                   while (len(contours) >= 2):
                         c1 = min(contours, key = cv2.contourArea)
                         contours.remove(c1)
      except:
            print('error check label exists')
      print('Length of contours-testafter: check_lablels_exist()',len(contours))
      cnt = contours[0]
      S_label = int(cv2.contourArea(cnt))
      if (S_label < (S_good_label / 2)):
            label_exist = False
      else:
            label_exist = True
      return label exist
# ------
# Find the height of label (y axis)
def find_labels(image):
      image_h, image_w, _ = image.shape
      center_img = image[:, int(image_w * 0.03): int(image_w * 0.97)]
      binary = label_segmentation(image)
      cv2.imshow('binary-find labels',binary)
      contours,
                                   cv2.findContours(binary, cv2.RETR_TREE,
cv2.CHAIN_APPROX_SIMPLE)
```

```
print('Length of contours-testbefore: find_lablels()',len(contours))
       try:
              if (len(contours) >= 2):
                     c = max(contours, key = cv2.contourArea)
                      contours.remove(c)
                      while (len(contours) \geq 2):
                             c1 = min(contours, key = cv2.contourArea)
                             contours.remove(c1)
       except:
              print('error find label')
       print('Length of contours-testafter: find_lablels()',len(contours))
       binary = cv2.drawContours(binary, contours, -1, (100,87,51),3)
       hull = [cv2.convexHull(c) for c in contours]
       binary = cv2.drawContours(binary,hull,-1,(100,87,55),3)
       label_y_arr = []
       for num, cnt in enumerate(contours):
              x, y, w, h = cv2.boundingRect(cnt)
    # Getting ROI
              roi = image[y:y+h, x:x+w]
              # show ROI
              cv2.rectangle(center_img,(x,y),(x+w,y+h),(255,0,0),2)
              cv2.imshow('marked label areas',center_img)
              if (y > (BANG_HEIGHT * image_h)):
                     label_y_arr.append(y)
                     label_y_arr.append(y + h)
       min_label_y, max_label_y = 0, 0
       if label_y_arr:
              min_label_y = min(label_y_arr)
              max_label_y = max(label_y_arr)
       return min_label_y, max_label_y
# Find the exact ratio between label and bottle
def right_labels():
       image = input_image('D:\\Testimg\\Bottle_checking (CC)\\good1.jpg')
       binary = label_segmentation(image)
       image_h, image_w, _ = image.shape
```

```
center_img = image[:, int(image_w * 0.0\overline{3}): int(image_w * 0.97)]
                                     cv2.findContours(binary,
                                                                  cv2.RETR_TREE,
       contours,
cv2.CHAIN APPROX SIMPLE)
       try:
             if (len(contours) >= 2):
                    c = max(contours, key = cv2.contourArea)
                    contours.remove(c)
                    while (len(contours) >= 2):
                           c1 = min(contours, key = cv2.contourArea)
                           contours.remove(c1)
       except:
             print('error right label')
       cnt = contours[0]
       S_{label} = cv2.contourArea(cnt)
       binary = cv2.drawContours(binary, contours, -1, (100,87,51),3)
      hull = [cv2.convexHull(c) for c in contours]
       binary = cv2.drawContours(binary,hull,-1,(100,87,55),3)
       label_y_arr = []
       for num, cnt in enumerate(contours):
             x, y, w, h = cv2.boundingRect(cnt)
    # Getting ROI
             roi = image[y:y+h, x:x+w]
             # show ROI
             cv2.rectangle(center\_img,(x,y),(x+w,y+h),(255,0,0),2)
             if (y > (BANG_HEIGHT * image_h)):
                    label_y_arr.append(y)
                    label_y_arr.append(y + h)
       min_label_y, max_label_y = 0, 0
       if label y arr:
             min_label_y = min(label_y_arr)
             max_label_y = max(label_y_arr)
       return S_label, min_label_y, max_label_y
# ------
# Find the liquid level ratio
def find_liquid_level(image):
      image_h, image_w, _ = image.shape
```

```
center_img = image[:, int(i\overline{\text{mage}}_{\text{w}} * 0.03): int(image w * 0.97)]
       binary = liqlevel_segmentation(image)
       binary_copy = binary.copy()
       binary_copy = cv2.bitwise_not(binary_copy)
       components = cv2.connectedComponentsWithStats(binary copy, connectivity=8,
ltype=cv2.CV_32S)
       _, labelmap, stats, centers = components
       # S of label
       st_s = stats[:, 4]
       s_{argest} = np.argmax(st_s)
       stats1 = np.delete(stats,s_largest,0)
       # The width of label
       st_w = stats1[:, 2]
       # y0
       st_y = stats1[:, 1]
       w_{largests} = [np.argmax(st_w)]
       W = np.where(st_w > (image_w / 2))
       st_w_arg = W[0]
       number_label = len(st_w_arg)
       if (len(st_w_arg) > 1):
              y_min_arg = np.argmin(st_y)
              left_liq = stats1[y_min_arg,0]
              top_liq = stats1[y_min_arg,1]
              right_liq = left_liq + stats1[y_min_arg,2]
              bottom_liq = top_liq + stats1[y_min_arg,3]
       y_min_arg = np.argmin(st_y)
       left_liq = stats1[y_min_arg,0]
       top_liq = stats1[y_min_arg,1]
       right_liq = left_liq + stats1[y_min_arg,2]
       bottom_liq = top_liq + stats1[y_min_arg,3]
       return top_liq
# Find the exact ratio between liquid and bottle
def right_liquid_level():
       image = input_image('D:\\Testimg\\Bottle_checking (CC)\\good1.jpg')
       image_gray = cv2.cvtColor(image,cv2.COLOR_BGR2GRAY)
```

```
image\_gray = cv2.GaussianBlur(image\_gray, (5,5), 0)
      ret, image_binary = cv2.threshold(image_gray,50,255,cv2.THRESH_BINARY |
cv2.THRESH OTSU)
      image_binary_Gauss = cv2.GaussianBlur(image_binary, (15,15), 15)
             image binary2
                           =
                                 cv2.threshold(image_binary_Gauss,
                                                                   50,
                                                                          255,
cv2.THRESH_BINARY | cv2.THRESH_OTSU)
      image_binary2_Gauss = cv2.GaussianBlur(image_binary2, (15,15), 15)
             image_binary3 = cv2.threshold(image_binary2_Gauss,
                                                                    50,
                                                                          255,
cv2.THRESH_BINARY | cv2.THRESH_OTSU)
      # Find and Draw contours
      contours,
                                         hierarchy
cv2.findContours(image_binary3,cv2.RETR_TREE,cv2.CHAIN_APPROX_SIMPLE)
      image_binary3c = cv2.drawContours(image_binary3, contours, -1, (100,87,51),3)
      hull = [cv2.convexHull(c) for c in contours]
      image_binary3c_final = cv2.drawContours(image_binary3,hull,-1,(100,87,55),3)
      #-----
      # Remove the largest contours
      if (len(contours) >= 3):
            c = max(contours, key = cv2.contourArea)
            contours.remove(c)
            while (len(contours) \geq 3):
                   c1 = min(contours, key = cv2.contourArea)
                   contours.remove(c1)
      #-----
      #Draw ROI with the bottle
      #sort contours
      orig1 =image.copy()
      sorted_ctrs = sorted(contours, key=lambda ctr: cv2.boundingRect(ctr)[0])
      # print('Number of contour',len(contours))
      for i, ctr in enumerate(sorted ctrs):
            # Get bounding box
            x, y, w, h = cv2.boundingRect(ctr)
      # Getting ROI
            roi = image[y:y+h, x:x+w]
      #-----
      #Test draw contour and calculate distance
```

```
colors = ((0, 0, 255), (240, 0, 159), (0, 165, 255), (255, 255, 0), (255, 0, 255))
refObj = None
# loop over the contours individually
for c in sorted_ctrs:
       # if the contour is not sufficiently large, ignore it
       if cv2.contourArea(c) < 100:
               continue
       # compute the rotated bounding box of the contour
       box = cv2.minAreaRect(c)
       box = cv2.cv.BoxPoints(box) if imutils.is_cv2() else cv2.boxPoints(box)
       box = np.array(box, dtype="int")
       # order the points in the contour such that they appear
       # in top-left, top-right, bottom-right, and bottom-left
       # order, then draw the outline of the rotated bounding
       # box
       box = perspective.order_points(box)
       # compute the center of the bounding box
       cX = np.average(box[:, 0])
       cY = np.average(box[:, 1])
       # if this is the first contour we are examining (i.e.,
       # the left-most contour), we presume this is the
       # reference object
       if refObj is None:
               # unpack the ordered bounding box, then compute the
               # midpoint between the top-left and top-right points,
               # followed by the midpoint between the top-right and
               # bottom-right
               (tl, tr, br, bl) = box
               (tlblX, tlblY) = midpoint(tl, bl)
               (trbrX, trbrY) = midpoint(tr, br)
               (tltrX, tltrY) = midpoint(tl, tr)
               (blbrX, blbrY) = midpoint(bl, br)
               bottle_y2 = int(bl[1])
               bottle_x1 = int(tl[0])
               bottle_x2 = int(tr[1])
               # compute the Euclidean distance between the midpoints,
```

```
# then construct the reference object
                       D = dist.euclidean((tlblX, tlblY), (trbrX, trbrY))
                       refObj = (box, (cX, cY), D / 5.78)
                       continue
               # draw the contours on the image
               orig = image.copy()
               cv2.drawContours(orig, [box.astype("int")], -1, (0, 255, 0), 2)
               cv2.drawContours(orig, [refObj[0].astype("int")], -1, (0, 255, 0), 2)
               cv2.circle(orig, (int(blbrX), int(blbrY)), 5, (50,115,255), -1)
               D1 body = dist.euclidean((tltrX, tltrY), (blbrX, blbrY)) / refObj[2]
               # print('the length of bottle body', D1_body)
               # stack the reference coordinates and the object coordinates
               # to include the object center
               refCoords = np.vstack([refObj[0], refObj[1]])
               objCoords = np.vstack([box, (cX, cY)])
               box_copy = box
               (tl2, tr2, br2, bl2) = box\_copy
               (tltrX2, tltrY2) = midpoint(tl2, tr2)
               (blbrX2, blbrY2) = midpoint(bl2, br2)
               bottle_y1 = int(tl2[1])
               cv2.circle(orig, (int(tltrX2), int(tltrY2)), 5, (50,115,255), -1)
               cv2.line(orig, (int(blbrX), int(blbrY)), (int(tltrX2), int(tltrY2)),(50,115,255),
2)
               Bottle_height = dist.euclidean((blbrX, blbrY), (tltrX2, tltrY2)) / refObj[2]
               Bottle_position = np.array([bottle_x1,bottle_x2,bottle_y1, bottle_y2])
               (bottleX, bottleY) = midpoint((blbrX, blbrY), (tltrX2, tltrY2))
                                       "{:.1f}cm".format(Bottle height),
               cv2.putText(orig,
                                                                                (int(bottleX),
int(bottleY - 10)),cv2.FONT_HERSHEY_SIMPLEX, 0.55, (50,115,255), 2)
               for ((xA, yA), (xB, yB), color) in zip(refCoords, objCoords, colors):
                       # draw circles corresponding to the current points and
                       # connect them with a line
                       cv2.circle(orig, (int(xA), int(yA)), 5, color, -1)
                       cv2.circle(orig, (int(xB), int(yB)), 5, color, -1)
                       cv2.line(orig, (int(xA), int(yA)), (int(xB), int(yB)),color, 2)
                       # compute the Euclidean distance between the coordinates,
                       # and then convert the distance in pixels to distance in
```

```
# units
                    D = dist.euclidean((xA, yA), (xB, yB)) / refObj[2]
                    (mX, mY) = midpoint((xA, yA), (xB, yB))
                                       "{:.1f}cm".format(D),
                    cv2.putText(orig,
                                                             (int(mX),
                                                                        int(mY
10)),cv2.FONT_HERSHEY_SIMPLEX, 0.55, color, 2)
             cv2.imshow('Ratio distance ',orig)
      Ratio_liquidvsbottle = D1_body / Bottle_height
      return Ratio liquidysbottle, Bottle position
def find_bottle(image):
      Bottle\_height = 0
      Bottle_position = 0
      # Gaussian filter and threshold segmentation (Binary and Otsu)
      image_gray = cv2.cvtColor(image,cv2.COLOR_BGR2GRAY)
      image\_gray = cv2.GaussianBlur(image\_gray, (5,5), 0)
      ret, image_binary = cv2.threshold(image_gray,50,255,cv2.THRESH_BINARY |
cv2.THRESH_OTSU)
      image_binary_Gauss = cv2.GaussianBlur(image_binary, (15,15), 15)
                                       image_binary2
cv2.threshold(image_binary_Gauss,50,255,cv2.THRESH_BINARY
cv2.THRESH OTSU)
      image_binary2_Gauss = cv2.GaussianBlur(image_binary2, (15,15), 15)
                                       image_binary3
cv2.threshold(image_binary2_Gauss,50,255,cv2.THRESH_BINARY
cv2.THRESH OTSU)
      binary = image_binary3.copy()
      kernel = cv2.getStructuringElement(cv2.MORPH_RECT, (15, 15))
      binary = cv2.morphologyEx(binary, cv2.MORPH_OPEN, kernel)
      cv2.imshow('before using connect',binary)
      binary =cv2.bitwise_not (binary)
      number_label, mask_bin = ConnectedComponents(binary)
      binary = cv2.bitwise_and(binary,mask_bin)
      binary = cv2.bitwise_not(binary)
      image_binary4 = binary.copy()
      # Find and Draw contours
                                            hierarchy
      contours,
cv2.findContours(binary,cv2.RETR_TREE,cv2.CHAIN_APPROX_SIMPLE)
      # Remove the largest contours
```

```
try:
       if (len(contours) >= 3):
              c = max(contours, key = cv2.contourArea)
              contours.remove(c)
              while (len(contours) >= 3):
                      c1 = min(contours, key = cv2.contourArea)
                      contours.remove(c1)
except:
       print('error find bottle')
image\_binary3c = cv2.drawContours(binary, contours, -1, (100,87,51),3)
hull = [cv2.convexHull(c) for c in contours]
image_binary3c_final = cv2.drawContours(binary,hull,-1,(100,87,55),3)
#Draw ROI with the bottle
#sort contours
org1 = image.copy()
sorted_ctrs = sorted(contours, key=lambda ctr: cv2.boundingRect(ctr)[0])
for i, ctr in enumerate(sorted_ctrs):
       # Get bounding box
       x, y, w, h = cv2.boundingRect(ctr)
# Getting ROI
       roi = image[y:y+h, x:x+w]
       cv2.rectangle(org1,(x,y),(x+w,y+h),(255,0,0),2)
       cv2.imshow('marked areas - test',org1)
#Test draw contour and calculate distance
colors = ((0, 0, 255), (240, 0, 159), (0, 165, 255), (255, 255, 0), (255, 0, 255))
refObj = None
# loop over the contours individually
# print('length sorted_ctrs',len(sorted_ctrs))
for c in sorted_ctrs:
       # if the contour is not sufficiently large, ignore it
       if cv2.contourArea(c) < 100:
              continue
       # compute the rotated bounding box of the contour
       box = cv2.minAreaRect(c)
       box = cv2.cv.BoxPoints(box) if imutils.is_cv2() else cv2.boxPoints(box)
       box = np.array(box, dtype="int")
```

```
# order the points in the contour such that they appear
# in top-left, top-right, bottom-right, and bottom-left
# order, then draw the outline of the rotated bounding
# box
box = perspective.order_points(box)
# compute the center of the bounding box
cX = np.average(box[:, 0])
cY = np.average(box[:, 1])
# if this is the first contour we are examining (i.e.,
# the left-most contour), we presume this is the
# reference object
if refObj is None:
       # unpack the ordered bounding box, then compute the
       # midpoint between the top-left and top-right points,
       # followed by the midpoint between the top-right and
       # bottom-right
       (tl, tr, br, bl) = box
       (tlblX, tlblY) = midpoint(tl, bl)
       (trbrX, trbrY) = midpoint(tr, br)
       (tltrX, tltrY) = midpoint(tl, tr)
       (blbrX, blbrY) = midpoint(bl, br)
       bottle_y2 = int(bl[1])
       bottle_x1 = int(tl[0])
       bottle_x2 = int(tr[1])
       # compute the Euclidean distance between the midpoints,
       # then construct the reference object
       D = dist.euclidean((tlblX, tlblY), (trbrX, trbrY))
       D1_body = dist.euclidean((tltrX, tltrY), (blbrX, blbrY))
       refObj = (box, (cX, cY), D / 5.72)
       continue
# draw the contours on the image
orig = image.copy()
cv2.drawContours(orig, [box.astype("int")], -1, (0, 255, 0), 2)
cv2.drawContours(orig, [refObj[0].astype("int")], -1, (0, 255, 0), 2)
cv2.circle(orig, (int(blbrX), int(blbrY)), 5, (50,115,255), -1)
# stack the reference coordinates and the object coordinates
```

```
# to include the object center
               refCoords = np.vstack([refObj[0], refObj[1]])
               objCoords = np.vstack([box, (cX, cY)])
               box_copy = box
               (tl2, tr2, br2, bl2) = box copy
               (tltrX2, tltrY2) = midpoint(tl2, tr2)
               (blbrX2, blbrY2) = midpoint(bl2, br2)
               bottle_y1 = int(tl2[1])
               cv2.circle(orig, (int(tltrX2), int(tltrY2)), 5, (50,115,255), -1)
               cv2.line(orig, (int(blbrX), int(blbrY)), (int(tltrX2), int(tltrY2)),(50,115,255),
2)
               Bottle_height = dist.euclidean((blbrX, blbrY), (tltrX2, tltrY2)) / refObj[2]
               Bottle_position = np.array([bottle_x1,bottle_x2,bottle_y1, bottle_y2])
               (bottleX, bottleY) = midpoint((blbrX, blbrY), (tltrX2, tltrY2))
               cv2.putText(orig,
                                      "{:.1f}cm".format(Bottle_height),
                                                                               (int(bottleX),
int(bottleY - 10)),cv2.FONT_HERSHEY_SIMPLEX, 0.55, (50,115,255), 2)
               for ((xA, yA), (xB, yB), color) in zip(refCoords, objCoords, colors):
                      # draw circles corresponding to the current points and
                      # connect them with a line
                      cv2.circle(orig, (int(xA), int(yA)), 5, color, -1)
                      cv2.circle(orig, (int(xB), int(yB)), 5, color, -1)
                      cv2.line(orig, (int(xA), int(yA)), (int(xB), int(yB)),color, 2)
                      # compute the Euclidean distance between the coordinates,
                      # and then convert the distance in pixels to distance in
                      # units
                      D = dist.euclidean((xA, yA), (xB, yB)) / refObj[2]
                      (mX, mY) = midpoint((xA, yA), (xB, yB))
                      cv2.putText(orig,
                                           "{:.1f}cm".format(D),
                                                                    (int(mX),
                                                                                 int(mY
10)),cv2.FONT HERSHEY SIMPLEX, 0.55, color, 2)
               cv2.imshow('Bottle mask ',orig)
       return image_binary4, Bottle_height, D1_body, Bottle_position
# Draw text result
def draw_textresult(image, label_exist, label_ok, liquid_ok):
       labelstatus = ""
       if (label_exist == False):
```

```
labelstatus = "NO LABEL"
      else:
             if (label_ok == True):
                    labelstatus = "OK"
             elif (label ok == False):
                    labelstatus = "BAD"
      cv2.putText(image,"Label
                                                                            position:
{:.10s}".format(labelstatus),(10,20),cv2.FONT HERSHEY SIMPLEX,0.5,(0,146,152),2)
      # -----
      liquidstatus = ""
      if (liquid_ok == True):
             liquidstatus = "OK"
      elif (liquid_ok == False):
             liquidstatus = "BAD"
      cv2.putText(image,"Liquid
                                                  {:.10s}".format(liquidstatus),(10,40),
                                     volume:
cv2.FONT_HERSHEY_SIMPLEX,0.5,(0,146,152),2)
      return image
# Handle image to process image
def handle_image(img,rightlabel,rightliquid):
      right_liquid_max = right_liquid[0]
      right_liquid_min = rightliquid[1]
      S_good_label = rightlabel[0]
      label_rightbottom = rightlabel[1]
      label_rightheight = rightlabel[2]
      label_rightbottom_max = rightlabel[3]
      label_rightbottom_min = rightlabel[4]
      label_rightheight_max = rightlabel[5]
      label_rightheight_min = rightlabel[6]
      img_h, img_w, _ = img.shape
      img_e = cv2.cvtColor(img, cv2.COLOR_BGR2RGB)
      border = int(img_h * CUT_BORDER)
      image = img[:, border:(img_w -border)]
      image_h, image_w, _ = image.shape
      image_original = np.copy(image)
      pre_roi = get_roi(image, int(image_w * 0.2), int(image_w * 0.8))
```

```
pre_mask = cv2.bitwise_not(find_background(image, pre_roi))
      kernel = cv2.getStructuringElement(cv2.MORPH_RECT, (5, 5))
      pre_mask = cv2.morphologyEx(pre_mask, cv2.MORPH_OPEN, kernel)
      bin1, Bottle height, Bottle body, Bottle position = find bottle(image)
      left border, right border, roi width = get pre borders (bin1)
      cut_img1 = image[:, (left_border - roi_width):(right_border + roi_width)]
      cut_img1_h, cut_img1_w, _ = cut_img1.shape
      bottle_test1 = cut_img1.copy()
      bottle_test2 = cut_img1.copy()
      bottle_test3 = cut_img1.copy()
      roi = get_roi(cut_img1, roi_width, cut_img1_w - roi_width)
      ROI_EXT = int(cut_img1_w * 0.05)
      cut_img2 = cut_img1[:, (roi_width - ROI_EXT):(cut_img1_w - roi_width +
ROI_EXT)]
      cut_img2_h, cut_img2_w, _ = cut_img2.shape
      ROI EXT21 = int(cut img2 w * 0.05)
      ROI EXT22 = int(cut img2 h * 0.05)
      cut_bin,Bottle_height1, _,Bottle_position1 = find_bottle(cut_img2)
                                        cut_img2[(Bottle_position1[2]
      cut img
ROI_EXT22):(Bottle_position1[3]+ROI_EXT22)
                                                              (Bottle_position1[0]-
ROI_EXT21):(Bottle_position1[1]+ROI_EXT21)]
      bottle = cut_img
      bottle_h, bottle_w, _ = bottle.shape
      BottleHeight = (Bottle_position1[3] - Bottle_position1[2])
      # -----
      # Check the quality of label
      # -----
      labelexist = check label exist(bottle test1,S good label)
      # Check the existence of label
      if (labelexist == True):
             print('Bottle has label')
      else:
             print('Bottle has no label')
      label_ok = False
      label\_bottom = 0
```

```
label_height = 0
      # Check the position and the height of label
      if (labelexist == True):
             minlabely, maxlabely = find_labels(bottle_test2)
             # print('min label y', minlabely)
             # print('max label y', maxlabely)
             label_bottom = 1 - ((maxlabely - Bottle_position1[2]) / (Bottle_position1[3])
- Bottle_position1[2]))
             label_height = (maxlabely - minlabely) / (Bottle_position1[3]
Bottle_position1[2])
             print('label_bottom',label_bottom)
             print('label_height',label_height)
                (label_bottom > label_rightbottom_min) and
                                                                (label_bottom
label_rightbottom_max):
                    if (label_height > label_rightheight_min) and (label_height <
label_rightheight_max):
                          label ok = True
             print('Check if label is ok: ', label ok)
      # ------
      # Check the liquid level
      # ------
      liquid_level_y = find_liquid_level(bottle_test3)
      liquid_level = 1 - ((liquid_level_y - Bottle_position1[2]) / (Bottle_position1[3] -
Bottle_position1[2]))
      print('liquid level', liquid_level)
      liquid_ok = False
      if (liquid_level > right_liquid_min) and (liquid_level < right_liquid_max):
             liquid_ok = True
      print('Check if liquid level is ok: ', liquid_ok)
      recognize_info = label_height, label_bottom, liquid_level, labelexist, label_ok,
liquid_ok
      # -----
      # Draw text result to image
      result_image = draw_textresult(image,labelexist,label_ok,liquid_ok)
      cv2.imshow('the result of bottle checking', image)
      return result_image, recognize_info
```

```
# Save image
# def save_img(result_image, result_path, file_name):
#-----
# Capture camera from webcam
def capture_cam(captures_path, result_path,right_label_matrix, right_liquid_matrix):
      cap = cv2.VideoCapture(0)
      cap.set(3, 1280)
      cap.set(4, 960)
      recognize_info = None
      while (True):
             ret, frame = cap.read()
             if not ret:
                    print("No capture")
                    break
             if recognize_info:
                    frame
                                                              draw_textresult(frame,
recognize_info[3],recognize_info[4],recognize_info[5])
             cv2.imshow('Bottle check', frame)
             k = cv2.waitKey(100)
             if k == 27: # Esc key to stop
                    break
             elif k == 32: # Space key to recognize
                    # Upon the initial click of <Space> the current frame is
                    # recognized, the rendering of the results in the display
                    # window received from the webcam and saving of the images
                    # are performed.
                    # The second click on <Space> will clear the rendering of the
                    # results of recognition and make the process ready to repeat itself.
                    if recognize_info:
                           recognize_info = None
                    else:
                           file name
datetime.now().strftime("%Y%m%d-%H%M%S-%f.png")
                           cv2.imwrite(os.path.join(captures_path, file_name), frame)
```


```
result_image,
                                                          recognize_info
handle_image(frame,right_label_matrix, right_liquid_matrix)
                             # save_img(result_image, result_path, file_name)
                             cv2.imwrite(os.path.join(result_path,
file_name),result_image)
       cap.release()
       cv2.destroyAllWindows()
# Take video from path and process
def
        capture video(video path,
                                        captures path,
                                                           result path, right label matrix,
right_liquid_matrix):
       cap = cv2. VideoCapture(video_path)
       cap.set(3, 1280)
       cap.set(4, 960)
       recognize_info = None
       while (True):
              ret, frame = cap.read()
              if not ret:
                      print("No capture")
                      break
              if recognize_info:
                      frame
                                                                   draw textresult(frame,
recognize_info[3],recognize_info[4],recognize_info[5])
              cv2.imshow('Bottle check', frame)
              k = cv2.waitKey(100)
              if k == 27: # Esc key to stop
                      break
              elif k == 32: # Space key to recognize
                      # Upon the initial click of <Space> the current frame is
                      # recognized, the rendering of the results in the display
                      # window received from the webcam and saving of the images
                      # are performed.
                      # The second click on <Space> will clear the rendering of the
                      # results of recognition and make the process ready to repeat itself.
                      if recognize_info:
                             recognize_info = None
                      else:
```

```
file name
datetime.now().strftime("%Y%m%d-%H%M%S-%f.png")
                            cv2.imwrite(os.path.join(captures path, file name), frame)
                                         cv2.resize(frame,
                                                             None,
                                                                      fx=0.7,
                                                                                fy=0.7,
interpolation=cv2.INTER CUBIC)
                            result_image,
                                                        recognize_info
handle_image(frame,right_label_matrix, right_liquid_matrix)
                            # save img(result image, result path, file name)
                            cv2.imwrite(os.path.join(result_path,
file name), result image)
       cap.release()
       cv2.destroyAllWindows()
def main():
              # Find the exact ratio between liquid level and the height of bottle
              # Find the exact ratio between the height of label and the height of bottle
              #-----
              right_ratio, Bottle_rightposition = right_liquid_level()
              right liquid max = right ratio + 0.02
              right_liquid_min = right_ratio - 0.02
              right_liquid_matrix = right_liquid_max, right_liquid_min
              print('Ratio between the height of bottle and the liquid level', right_ratio)
              S_good_label,min_rightlabel_y, max_rightlabel_y = right_labels()
              S_good_label = int(S_good_label)
              # print('The area of good label', S_good_label)
              label_rightbottom = 1 - ((max_rightlabel_y - Bottle_rightposition[2]) /
(Bottle_rightposition[3] - Bottle_rightposition[2]))
              label_rightheight
                                       (max_rightlabel_y
                                                                 min_rightlabel_y)
(Bottle_rightposition[3] - Bottle_rightposition[2])
              label\_rightbottom\_max = label\_rightbottom + 0.03
              label_rightbottom_min = label_rightbottom - 0.03
              label\_rightheight\_max = label\_rightheight + 0.01
              label_rightheight_min = label_rightheight - 0.01
              right_label_matrix = S_good_label, label_rightbottom, label_rightheight,
                                                                 label_rightheight_max,
label_rightbottom_max,
                                label_rightbottom_min,
label_rightheight_min
              print('label_rightbottom_max ',label_rightbottom_max )
```

3.4 Kết quả đạt được

Sau khi test với các trường hợp, mô hình của nhóm thực hiện đã đạt kết quả tốt, với tỉ lệ chính xác 100%, với loại chai Coca-Cola







Nhãn TÔT, mực nước TỐT



Nhãn TÔT, mực nước TỐT



Nhãn TÔT, mực nước KÉM



Nhãn TÔT, mực nước KÉM




Nhãn TÔT, mực nước KÉM



Nhãn KÉM, mực nước KÉM



Nhãn KÉM, mực nước KÉM



Nhãn KHÔNG CÓ, mực nước KÉM



Nhãn KÉM, mực nước KÉM